



ROADSIDE DITCH AND ABUTTING WETLAND
WITH NO "RELATIVELY PERMANENT FLOW" INDICATORS

(OHWM Used To Establish Relatively Permanent Flows)